

Pentapharm® BlisterPro™

Predicting Blister Moisture Vapor Transmission Rates

Do you need to protect your pharmaceutical product against moisture? Cavity shape is an important factor. With Pentapharm® BlisterPro™ software, you can design the optimal blisters for your product. At kp, we believe in meeting the needs of our pharmaceutical clients comprehensively. That's why we offer BlisterPro™ as part of a complete package of films and support. At kp, we deliver.

In many cases, a moisture vapor transmission rate for a drug product from stability data has already been defined. With these data, kp can model the barrier performance of the cavity and predict the moisture vapor transmission rate of a cavity in, for example, units of mg/blister/day. This often helps determine if a package can meet the requirements either outlined in regulatory literature or by stability testing.


Since changes to geometry can have a large effect on performance, Pentapharm® BlisterPro™ works well to check production tool designs versus the results given by stability tools. This provides package engineers with a better level of detail in order to make a more informed decision.

"Twenty Count" Tablet

0.28 mm³

0.027 mg/day - experiment

0.036 mg/day - Pentapharm® BlisterPro™




"Size One" Capsule

1.00 mm³

0.148 mg/day - experiment

0.142 mg/day - Pentapharm® BlisterPro™




"Double" Capsule

4.02 mm³

0.313 mg/day - experiment

0.311 mg/day - Pentapharm® BlisterPro™




"Square" Tablet

2.09 mm³

0.195 mg/day - experiment

0.194 mg/day - Pentapharm® BlisterPro™




"Round" Tablet

1.10 mm³

0.101 mg/day - experiment

0.111 mg/day - Pentapharm® BlisterPro™



kp performed testing for Pentapharm® ACLAR® 200 S03 film made on 5 different tool shapes in order to provide information on both the error of prediction and to gain further confidence in the model. All blisters produced in this study used 5-mil vinyl skins and a 2-mil ACLAR® layer. The blisters ran with standard pressure-only conditions on a Körber Medipak CP-2.

Very often Pentapharm® BlisterPro™ demonstrates an accuracy of prediction to within approximately 10% of experimental data.

© 2008 Klöckner Pentaplast. All rights reserved.

ACLAR® is a registered trademark of Honeywell International Inc.

The statements contained herein are for informational purposes only and are true and accurate to the best of our scientific and technical knowledge. This information does not constitute a guarantee or warranty, express or implied, nor does it establish a legally valid contractual relationship. It is the customer's responsibility to determine the suitability of this product for the customer's intended use, and Klöckner Pentaplast does not assume any liability for the customer's use of this product or the information contained herein. (04/08)